
Meridian 1

Message Registration

Description and operation

Document Number: 553-2701-101

Document Release: Standard 4.00

Date: August 1996

© 1990, 1996

All rights reserved

Printed in the United States of America

Information is subject to change without notice. Northern Telecom reserves the right to make changes in design or components as progress in engineering and manufacturing may warrant. This equipment has been tested and found to comply with the limits for a Class A digital device pursuant to Part 15 of the FCC rules, and the radio interference regulations of Industry Canada. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy, and if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at their own expense.

SL-1 and Meridian 1 are trademarks of Northern Telecom.

Revision history

August 1996

Standard, Release 4.00. This document is reissued for X11 Release 22.0x.

December 1994

Standard, Release 3.00. This document is reissued to include editorial changes and indexing. Due to the extent of the changes, revision bars are not used.

December 1991

Standard, Release 2.00. This document is reissued to include technical content updates. Due to the extent of the changes, revision bars are not used.

August 1990

Standard, Release 1.00. This document is reissued for compliance with Northern Telecom standard 164.0.

Contents

Description	1
Feature interactions	3
Multiple Appearance Directory Numbers	3
Call Transfer	3
Call Forward	3
Conference	3
Trunk-to-trunk calls	3
Attendants	3
Operating parameters	4
Feature administration	4
Hardware description	4
Trunk circuit packs	4
Reverse Battery operation	5
 Operation	 9
Background terminal command summary	9
Setting room meters	10
Selecting a single DN	10
Selecting Multiple Appearance DNs	11
Access to meters	12

List of figures

Figure 1	
Trunk connections	7

List of tables

Table 1	
QPC330 and QPC331 trunk option switch settings	5
Table 2	
QPC219, QPC295 CO/FX/WATS trunk cards	6
Table 3	
MR commands	10
Table 4	
MR set commands	12

::553-4151.eps 7